



BUILT-IN OVEN

USER MANUAL

MBO7NP30E4-BK







Warning notices: Before using this product, please read this manual carefully and keep it for future reference. The design and specific tions are subject to change without prior notice for product improvement. Consult with your dealer or manufacturer for details.


The illustration is for reference only. Please take the appearance of the actual product as the standard.

PRODUCT INSTALLATION

Cupboard Diagram (Standing Cupboard)









ΕN


- Reserve 5 mm for the door panel at the top and bottom respectively.
- 2 Reserve 20 mm for the door panel on the left and right respectively.
- 3 Reserve 20 mm for the door panel in thickness.
- 1. The thickness of the cupboard board is 20 mm.
- 2. If the power socket is installed on the back of the appliance, the depth of the cupboard opening shall be increased from a minimum of 590 mm to 620 mm.
- 3. The dimensions in the figures are in mm

Cupboard Diagram (Ground Cupboard)







ΕN



Minimum bottom ventilation area: 250 mm²



- Reserve 5 mm for the door panel at the top and bottom respectively.
- **2** Reserve 20 mm for the door panel on the left and right respectively.
- 3 Reserve 20 mm for the door panel in thickness.



If the appliance is installed under the hob, the minimum thickness of worktop A is shown below:

Hob type	worktop A
Induction hob	37 mm
Full-surface induction hob	47 mm
Gas hob	30 mm
Electric hob	27 mm

- 1. The thickness of the cupboard board is 20 mm.
- 2. If the power socket is installed on the back of the appliance, the depth of the cupboard opening shall be increased from a minimum of 590 mm to 620 mm.
- 3. The dimensions in the figures are in mm

Installation Important Instructions

Content that means [mandatory]

- 1. The safe operation of this appliance can only be guaranteed if it has been installed to a professional standard by these installation instructions. The installer shall be liable for any damage resulting from incorrect installation.
- 2. The entire installation process requires two professional installers. Wear dry protective gloves during installation to avoid scratches or electric shock.
- 3. Fitted units must be heat-resistant up to 90°C, and adjacent unit fronts up to 70°C.
- 4. Please use a 16A socket.

Ocontent that means [prohibit]

- 1. Do not install the appliance behind a decorative door or the door of a kitchen unit, as this may cause the appliance to overheat.
- 2. Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.
- 3. Do not block the vent of the appliance and the gap between the cupboard and the appliance.
- 4. Use extreme caution when moving or installing the appliance. It is very heavy, do not lift the appliance by the door handle.
- 5. If the power cord or power plug is damaged, stop using the appliance immediately, to avoid fire, electric shock or other injuries


Content that means [note]

- 1. Be very careful when moving or installing the appliance to avoid damage to the appliance or damage to the cupboards.
- 2. Before starting up the appliance, remove all packaging materials and accessories from the cavity.
- 3. The power socket shall be accessible to users (such as next to the cupboard) for easy power-o_i.
- 4. After installation is complete, make sure that the power plug is firmly inserted into the socket.
- 5. Please refer to the "Cupboard Diagram" for the requirements of net depth of the cupboard. The clearance between the cupboard bottom board and the rear board (or wall) shall not be less than 50 mm.

ΕN


Installation steps


- 1. Please customize the cupboard according to the "Cupboard Diagram".
- 2. Before installation, please check for normal power sockets and appropriate grounding, and check whether the cupboard dimension meets the installation requirements.
- 3. Place the appliance in designated locations in the kitchen, install it in a vertical cupboard, and connect the power supply.
- 4. To locate the mounting fixing holes, open the appliance door and look at the side frame of the appliance (position shown above).
- 5. Fix the appliance to the cupboard with two rubber plugs A and screws B provided with the appliance.





ΕN

Accessory installation










EN



Only for some models



