cecotec

TOTALPURE 1000 HANDY

Purificador de aire/ Air purifier



Manual de instrucciones
Instruction manual
Manuel d'instructions
Bedienungsanleitung
Manuale di istruzioni
Manual de instruções
Instrukcja obsługi
Návod k použití

1. PARTS AND COMPONENTS

Air purifier
Fig. 1.

1. Main body
2. Filter
3. Base

Control panel
Fig. 2.

1. Power
2. Speed setting
3. Timer

Air purifying system
Fig. 3.

1. Air inlet
2. Air outlet

2. BEFORE USE

Take the product out of the box.
Remove all packaging material. Save the original box.
Make sure all parts and components are included and in good conditions. If any visible signs of damage are observed, contact the Technical Support Service immediately.

3. OPERATION

Plug the device into a power supply. The device will beep, and all light indicators will turn on. After 3 seconds, the device will enter standby mode.
Press the Power button once, the power light indicator and the speed light indicator will turn on. The device will operate at speed 1 by default.
Press the Speed settings button consecutively to select the desired speed: 1, 2, 3 or "S".
1: Low speed
2: Medium speed
3: High speed
S: Sleep mode
Press the Timer button to select the number of hours the device will operate: 1, 3, 7 or 15. After

the device has operated for the set time, it will turn automatically off.
Press the Power button again to shut down.

4. CLEANING AND MAINTENANCE

Turn off and unplug the product from the power supply before cleaning or repairing it.
Use a soft, dry (or slightly damp) cloth with some neutral cleaning agent to clean the product's outside and prevent the accumulation of dust and dirt.
If the product is not going to be used for a long time, store it in a safe and well-ventilated place.
Do not use detergent, scouring pads, chemically-treated cloths, gasoline, benzene, alcohol, thinner, or other solvents, as these can scratch and damage the tank and cause water leakage.
Do not immerse the product in water or any other liquid.

Filters
Switch the device off to stop the air filter.
Unplug the device.
Rotate the base anticlockwise and remove it.
Take the high efficiency filter out.
Clean the filter with a cloth and shake it to remove all impurities. When necessary, replace the filter with a new on.
It is not suggested to wash the filter, as its filtering efficiency may be affected.
Replace the base by rotating it clockwise.

5. TECHNICAL SPECIFICATIONS

Product reference: 05624
Product: TotalPure 1000 Handy
25 W, 220-240 V~, 50 Hz

6. DISPOSAL OF OLD ELECTRICAL APPLIANCES



The European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), specifies that old household electrical appliances must not be disposed of with the normal unsorted municipal waste. Old appliances must be collected separately, in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment.

The crossed out "wheeled bin" symbol on the product reminds you of your obligation to dispose of the appliance correctly. If the product has a built-in battery or uses batteries, they should be removed from the appliance and disposed of appropriately.
Consumers must contact their local authorities or retailer for information concerning the correct disposal of old appliances and/or their batteries.

7. TECHNICAL SUPPORT SERVICE AND WARRANTY

This product is under warranty for 2 years from the date of purchase, as long as the proof of purchase is submitted, the product is in perfect physical condition, and it has been given proper use, as explained in this instruction manual.
The warranty will not cover the following situations:
The product has been used for purposes other than those intended for it, misused, beaten, exposed to moisture, immersed in liquid or corrosive substances, as well as any other fault attributable to the customer.
The product has been disassembled, modified, or repaired by persons, not authorised by the official Technical Support Service of Cecotec.
Faults deriving from the normal wear and tear of its parts, due to use.
The warranty service covers every manufacturing defects of your appliance for 2 years, based on current legislation, except consumable parts. In the event of misuse, the warranty will not apply.
If at any moment you detect any problem with your product or have any doubt, do not hesitate to contact Cecotec Technical Support Service at +34 963 210 728.